

**Trolley-mounted refilling unit
RKT/E01-X2 RKT/57-X2 12V, 230V, BB 25/50 litres
with dual dispensing device for traditional and float plugs**



RKT/E01-X2 12V, 230V, BB refilling units are devices for topping up batteries. They are equipped with a dual handle that allows batteries to be topped up using both float plugs and traditional plugs.

One device for all refilling operations; the two dispensing devices are easily interchangeable. It operates with a submerged pump at 12, 24, 220V and with a 25-litre or 50-litre water drum. A 220V version is available, as well as an onboard battery version with battery charger supplied.



RKT/E01-X2 25 litres

MACHINE FEATURES



Ref.	Description	Spare part code
1	P/2000 dispensing gun	RKT-E01X2/P2000
2	Dispensing sleeve	RKT-E01X2/manicotto
3	Sleeve / dispensing gun holder	RKT-E01X2/PP
4	Power clamps / Power plug	RKT-E01X2/4
5	Control box	RKT-E01X2/5
6	Polypropylene tank for demineralized water, 25-litre capacity	RKT-E01X2/6
7	Fixed wheels	RKT-E01X2/ruote
8	Demineralized water dispensing hose	RKT-E01X2/pvc8
9	Demineralized water filling cap	RKT-E01X2/TP
10	Start switch	RKT-E01X2/I
11	Support trolley with transport handle	RKT-E01X2/P
12	Sleeve / gun dispenser coupling	RKT-E01X2/innesto
13	Flow indicator	RKT-E01X2/girella
14	Empty drum warning light	RKT-E01X2/spia

P/2000-Ci2021 dispensing gun for traditional plugs



Grey dispensing sleeve for centralized watering float plugs

